

How to properly put on your WADE Right

Step 1: Unbuckle the top 1 inch buckle with one hand while holding both shoulder straps in your other hand



Step 2: Place both shoulder straps over your shoulders just as if you were putting on a back pack leaving the 2 inch belt strap buckled behind your lower back



Step 3: Clip the 1 inch strap and buckle across the chest



Step 4: Unbuckle the bottom 2 inch strap and adjust the bottom of the belt so that the suspender straps and belt are comfortable



Step 5: Clip the 2 inch strap and buckle in front of your waist and adjust to desired comfort



Step 6: Adjust each suspender to desired comfort



Step 7: Add all of your fishing gear to the grommets and D Rings and get ready to catch some fish.

